

Lenco


QUICK-GUIDE Windows 7 turntable

For information and support, www.lenco.eu


When using Windows 7 as operating system, the hard and software need to be configured in a different way than described in the instruction manual. This quick guide describes how you need to install the hard and software.

Note: Minimal system requirements are Windows 7 Home Premium.


1. Connect the turntable with the AC power outlet.
2. Connect the turntable with a USB socket on your computer and wait for several seconds until below pop-up screen appears.



3. Click on Close.
4. Click with the right mouse-button on the speaker icon (taskbar) and select Recording, below screen appears:
 5. Click on Microphone USB-audiodevice.
 6. Click on Properties.




7. Go to Tab Levels and slide the volume slider down to level 2 as shown in below example.
8. Go to Tab Advanced and select in the pull-down menu: 2 Channel, 16 bit, 44100 Hz (Cd-Quality).




9. Click on Apply, OK and OK again (now all programs are closed).
10. Insert the Audacity software CD into your disk drive or download free of charge new software via <http://audacity.sourceforge.net/>.
11. Run the installation as described in the instruction manual.
12. Run the Audacity software.

Lenco

13. Go to the taskbar and click on Edit and than on Preferences. Below screen will appear::



14. Select in the pull-down menu "Recording", "Device" the option Microphone (USB-audiodevice).
15. Select in the pull-down menu "Channels" the option 2 (stereo)
16. Mark the selection box "Software Playthrough (play new track while recording it)".
17. Click on OK.
18. Click on the microphone icon on the pull-down menu on start monitoring, as you can see in below picture.



The software is now set and you can start digitalising your records.

For information and support, www.lenco.eu