



# Lenco®



QUICK-GUIDE DTVR-700

## Preparation / installation:

Connect the power (see first image below)  
Connect the available antenna types (ATV/FM, DVB-T) to the correct antenna input of the unit (see second image below)


Insert the batteries into the remote control.

When using the unit without adapter please insert rechargeable batteries into the battery compartment. We recommend to use rechargeable batteries only. Please remove the batteries when the unit is not used for a longer period of time, the batteries will last longer.



ATV/FM antenna socket

DVB-T antenna socket



## Setup / Basic operation analogue TV:

- 1 Press the TV button on the remote control to select ATV mode
- 2 Press the SETUP button on the remote control to enter "ATV setup"
- 3 Use the up/down buttons on the remote control to select "TV FORMAT", press ENTER to confirm
- 4 Use the up/down buttons to select your TV format (most european countries use PAL BG), press ENTER to confirm
- 5 Press the return button on the remote to return
- 6 Use the up/down buttons on the remote control to select "AUTO SEARCH", press ENTER to confirm, autoscans will start.
- 7 Once the channels are stored, select the channels with the CH+/CH- buttons

## Setup / Basic operation DVB-T:

- 1 Press the DVB button on the remote control to select DVB-T mode
- 2 Select "Yes" when asked to use the "installation wizard", (use the left/right buttons to navigate and press ENTER to confirm)
- 3 Select your "country" and "menu language" (use the left/right/up/down buttons to navigate and press ENTER to confirm)
- 4 Select "yes" to start "auto-scan"
- 5 Use CH+/CH- to select channels

## Basic operation DVD/VCD/CD:

- 1 Open the TFT cover
- 2 Insert a DVD/CD (label facing up)
- 3 Wait until the unit reads the disc, it will show DVD, VCD or CD in the TFT display
- 4 The disc will be played automatically

Please refer to the manual for a more detailed explanation about the button functions.

