

# Lenco

## 3.5' Pocket DVB-T TV

Model: TFT-370











### User's Manual

## Table of content

1	Picture of the Portable TV .....	2
2	BASIC OPERATION.....	3
2.1	Power On/Off .....	3
2.2	Channel switch .....	3
2.3	Volume Control .....	3
2.4	Program list .....	3
2.5	Sub-menu .....	3
2.6	Deleting channels.....	4
2.7	Reset .....	4
3	System Setup .....	4
3.1	Country Scan.....	4
3.2	Manual Scan.....	4
3.3	System setting .....	4
3.4	Display setting .....	5
3.5	Factory Default .....	5
3.6	Version.....	5
4	Use of battery .....	5
5	Specifications.....	6


# 1 Picture of the Portable TV





	Menu Button
	Power Button / Return Button
	Channel +
	Channel -
	Vol +
	Vol -
<b>OK</b>	Confirm Button
 DC 5V/2A	DC Jack
 C	Earphone Jack

## 2 BASIC OPERATION

### 2.1 Power On/Off


Power On: Press  button and hold for 3 seconds, the system will start up.

Power Off: Press  button and hold for 3 seconds, the system will pop up a dialog box as follow:



Press OK to power off the player.



### 2.2 Channel switch

Press  to channel +/-.

### 2.3 Volume Control


Press +/- to increase or decrease the volume.


### 2.4 Program list

Press  under TV/Radio playback mode to show the program list and press  to select the TV/Radio channel, then press OK to confirm.


### 2.5 Sub-menu

Press OK under TV/Radio playback mode to enter the sub-menu as follow:



Move the cursor and press OK to enter these functions, and then you can press the Direction Key to select different option, press  to return and exit this sub-menu.


## 2.6 Deleting channels

While playing TV or radio press the  button to open the channel list, now press  $\pm$  and the system will show “Are you sure to delete current channel?”, select yes to delete the selected channel.

## 2.7 Reset

If the player suspend hanged up, please insert a sharp stick into the reset hole and press lightly, the system will clear all setting and power off.

# 3 System Setup


Press  to enter the system setup menu as follow:




## 3.1 Country Scan

Move the cursor to  and press OK to start COUNTRY SCAN base on the Country setting.


## 3.2 Manual Scan

Move the cursor to  and press OK to start MANUAL SCAN; you can set the start frequency, end frequency and Band width manually.


## 3.3 System setting

Move the cursor to  and press OK to enter system setting menu, you can set Area, Time Zone, OSD Language and LCN option.


### 3.4 Display setting

Move the cursor to  and press OK to enter Display Setting menu, you can set LCD Brightness, Contrast, Hue and Aspect Ratio option.

### 3.5 Factory Default

Move the cursor to  and press OK to load Factory Default setting.


### 3.6 Version

Move the cursor to  and press OK to show the Hardware and Software version information.

## 4 Use of battery

### Precautions

Please fully charge the battery when use the unit for the first time, at least 8 hours charging need for first 3 time charge to extend the life of the battery. The unit will be warmer when the unit is in use. It's normal. Please power off when the unit is not used for a long time. The unit will be automatically powered off when the battery is low.



### Warning

- Don't use the battery which does not match the unit. Danger of explosion will be caused if battery is incorrectly replaced. Replace only with batteries in the same or equivalent type.
- For charging the battery, the power switch should be turned off.
- Charge the battery with AC/DC adapter after switch off the unit.

### Warning

- The AC/DC adapter is AC adapter, the input voltage is 100V-240V, and the output voltage is 5V/2A. Danger of burning the unit may be resulted if the AC/DC adapter does not match the unit.

## 5 Specifications

<b>Specifications</b>	
Digital TV tuner	DVB-T module
Antenna	Built-in elastic antenna to receive the digital TV programs with sound signals
Panel	3.5" TFT-LCD Display with the resolution of 320*240
IO	- Earphone jack - DC-in Jack
Buttons	- Reset Hole - Volume key - Navigation key - Menu key - Esc key /power on/off
Battery	Lithium-Ion rechargeable battery (2400mAh, 3.7V) - Watch DTV 4 hours (Earphone Mode)
Dimensions	117 x 75 x 16.1 mm
Weight	165g with battery
Regulations	CE, RoHS
<b>Software Specification</b>	
Watch DVB-T programs	Support digital teletext, EPG, Subtitle.
Language	English
Channel Scan	Country scan / Manual scan
<b>List of accessories</b>	
Instruction manual	1 X
AC / DC Adaptor	1 X